

Installation Instructions for Würth Protective Film for Paintwork

Simple Installation:

Prior to the installation, the painted surface to be covered must be thoroughly cleaned and free from grease and dust. Remove any polish. Apply the film in a place protected against wind, dust and direct sunlight. Apply Würth protective film wet only. Do not apply to fresh paintwork!



1. Cut Würth protective film to the required size. Leave the required openings for license plates, key holes, fog lamps, etc. Mark the cut-outs for the license plate lights etc. with a felt marker and cut out the openings using a pair of scissors.

Simple Dismounting:

The Würth protective film can be pulled off, starting from a corner, in one piece and without leaving any residue. In order to be able to grip the corner of the film we recommend to warm up that area with a hair dryer.



2. Remove the backing paper. Soak the adhesive side of the film and the surface to which it is to be applied thoroughly with Würth installation fluid (spray bottle). Place the film in the desired position. The film can be stretched around bends or curves without wrinkling. Squeeze the installation fluid out from under the film using a squeegee, working in overlapping strokes from the middle towards the edge.

Attention:

The optimal adhesion of the film to the substrate takes about 48 hours. Up to that point, no adhesion tests should be made nor should the film be exposed to external influences (such as car washes, high pressure steam cleaners, etc.).



3. Should there still be any air or fluid bubbles, remove the protective film as far as required, spray once again with installation fluid and repeat the procedure. Remove any possibly existing wrinkles by gently heating the film with a hair dryer and working the wrinkles out with the squeegee.

Dimensions	Colour	Art. No.	Pack Qty.
10 cm x 10 m	transparent	0894 100 10	1
15 cm x 10 m		0894 100 15	
15 cm x 2 m		0894 100 150	
20 cm x 10 m		0894 100 20	
30 cm x 6 m		0894 100 30	

Accessories

Description	Contents	Art. Nosw.	Pack Qty.
Squeegee, blue	–	0691 500 120	1
Knife with break-off blade	–	0715 66 06	
Installation fluid spray bottle + gun (incl. medium)	500 ml	0893 455	

Technical Data

Carrier	polyurethane film
Colour	transparent
Adhesive	acrylate
Backing paper	adhesive-repellant paper, white
Total thickness	0.36 mm
Temperature stability	–40°C to +120°C briefly up to +135°C