

Dimensions	Colour	Art. No.	Pack Qty.
10 cm x 10 m	black	<b>0894 200 10</b>	1
15 cm x 10 m		<b>0894 200 15</b>	
20 cm x 10 m		<b>0894 200 20</b>	
30 cm x 6 m		<b>0894 200 30</b>	

For our customers wishing to test this high performance design film we offer a smaller packing unit with 2 m of film.

Dimensions	Colour	Art. No.	Pack Qty.
30 cm x 2 m	black	<b>0894 200 300</b>	1

## Technical Data

Carrier	polyurethane film
Surface finish	textured
Colour	black
Backing paper	adhesive-repellant paper, white
Total thickness	0.4 mm
Temperature stability	40°C to +120°C briefly up to +135°C

## Accessories

Squeegee, blue, **Art. No. 0691 500 120**, Pack Qty. 1  
Cutter with break-off blade, **Art. No. 0715 66 06**

## Installation Instructions for Würth Textured Design Film:

### Simple Installation:

Prior to the installation, the painted surface to be covered must be thoroughly cleaned and free from grease and dust. Remove any polish. Apply the film in a place protected against wind, dust and direct sunlight. Apply the textured design film dry only. Do not apply to fresh paintwork!

### Simple Removal:

The textured design film can be pulled off – starting from any corner – in one piece and without leaving any residue. In order to be able to grip the corner of the film we recommend to warm up that area with a hair dryer.

### Attention:

The optimal adhesion of the film to the substrate takes about 48 hours. Up to that point, no adhesion tests should be made nor should the film be exposed to external influences (such as car washes, high pressure steam cleaners, etc.).

1. Cut the textured design film to the required size. Leave the required openings for license plates, key holes, fog lamps, etc.
2. Remove the backing paper and place the film in the desired position. Using light pressure, press the film onto the surface with the squeegee, working in overlapping strokes from the middle towards the edge.
3. Should there still be any air bubbles, remove the textured design film as far as necessary and repeat the procedure. Remove any possibly existing wrinkles by gently heating the film with a hair dryer and working out the wrinkles with the squeegee.