

## CUTTING RING SCREW JOINTS

### CONNECTORS



Reducing connectors						
For pipe dia.	M	M	Max. oper. pressure in bar	Joint type	Art. No.	P. Qty.
-	22 x 1.5	16 x 1.5	20	-	0884 201 622	5



Reducing connectors						
For pipe dia.	M	M	Max. oper. pressure in bar	Joint type	Art. No.	P. Qty.
-	16 x 1.5	22 x 1.5	20	-	0884 192 216	5



Hose connectors with thread						
Hose dia.	M	Max. oper. pressure in bar	Joint type	Art. No.	P. Qty.	
11	16 x 1.5	20	-	0884 211 116	5	
11	22 x 1.5	20	-	0884 211 122	5	
13	16 x 1.5	20	-	0884 211 316	5	
13	22 x 1.5	20	-	0884 211 322	5	



Hose connectors						
Hose dia.	M	Max. oper. pressure in bar	Joint type	Art. No.	P. Qty.	
11	-	20	Butt	0884 351 152	5	
13	-	20	Butt	0884 351 352	5	



Union nut for hose connectors						
Hose dia.	M	Max. oper. pressure in bar	Joint type	Art. No.	P. Qty.	
17	22 x 1.5	-	Butt	0884 362 215	5	

### TEST CONNECTIONS



Union nut for hose connectors				
M	Max. oper. pressure in bar	Art. No.	P. Qty.	
16 x 1.5	20	0884 301 615	5	
22 x 1.5	20	0884 302 215	5	



Union nut for hose connectors				
M	Max. oper. pressure in bar	Art. No.	P. Qty.	
12 x 1.5	20	0884 311 215	5	



Union nut for hose connectors				
M	Max. oper. pressure in bar	Art. No.	P. Qty.	
22 x 1.5	20	0885 07 01	10	