

## INTAKE FILTER SIEVE RANGE



- For preventative protection of the replacement components e.g. following compressor damage
- Set contains 24 of the commonest interfaces, many vehicles covered by one range
- Insertion tool included
- No need to cut the pipes to size
- No additional seals required.
- Permanent protection against residual contamination

**Art. No. 0964 764,111**

P. Qty. 1

**Note:** An air-conditioning system must be emptied and evacuated before it is opened. Using the intake filter (SF) is not a substitute for purging the air conditioning after any compressor damage! Rather, intake filters provide preventative protection against renewed problems with residual contamination.

Fig.	Art. No.	Unicorn	P. Qty.
1	<b>0764 110 009</b>	SF 10.03 mm	3
2	<b>0764 110 010</b>	SF 10.26 mm	
3	<b>0764 110 011</b>	SF 11.07 mm	
4	<b>0764 110 012</b>	SF 11.76 mm	
5	<b>0764 110 001</b>	SF 11.96 mm	
6	<b>0764 110 013</b>	SF 12.00 mm	
7	<b>0764 110 014</b>	SF 12.50 mm	
8	<b>0764 110 015</b>	SF 12.70 mm	
9	<b>0764 110 002</b>	SF 12.95 mm	
10	<b>0764 110 003</b>	SF 13.23 mm	
11	<b>0764 110 004</b>	SF 13.49 mm	
12	<b>0764 110 005</b>	SF 13.67 mm	
13	<b>0764 110 006</b>	SF 14.02 mm	

Fig.	Art. No.	Unicorn	P. Qty.
14	<b>0764 110 016</b>	SF 14.25 mm	3
15	<b>0764 110 017</b>	SF 14.70 mm	
16	<b>0764 110 018</b>	SF 14.93 mm	
17	<b>0764 110 007</b>	SF 15.11 mm	
18	<b>0764 110 019</b>	SF 15.24 mm	
19	<b>0764 110 008</b>	SF 15.70 mm	
20	<b>0764 110 020</b>	SF 16.48 mm	
21	<b>0764 110 021</b>	SF 20.85 mm	
22	<b>0764 110 022</b>	SF 22.00 mm	
23	<b>0764 110 023</b>	SF 22.15 mm	
24	<b>0764 110 024</b>	SF for Denso 10PA17	
25		Insertion tool	