

## ELECTRODE WELDING INVERTER

### Operating devices electrode welding inverter ESI 150

Main switch: On/Off

Slot for carry strap

Fault indicator LED

Toggle switch  
for switching  
between electrode  
and TIG welding

Network indicator LED

Rotary switch for setting  
the welding current

Connection jacks  
for positive and negative  
poles +/-

Air outlet

