

## WINDSHIELD ADHESIVE RAPID



**Rapid, high-modulus 1-component windshield adhesive for primer-free working.**

### Short drive-away time

The vehicle is ready for use again after 1 hour

### High modulus

Vehicle-strengthening windshield adhesive that is also highly flexible thanks to new UHM technology (ultra-high modulus).

### Suitable for antennas, non-conductive

### Prevents contact corrosion

Suitable for use on aluminum, magnesium and hybrid vehicle bodies (e.g. Audi A8, Jaguar XJ etc.).

### Tested safety

- Drive-away time confirmed via crash testing and TÜV certificate pursuant to FMVSS 208/212.
- Meets the requirements of original equipment manufacturers (motor vehicle manufacturers).

Art. No.	0890 023 50		0890 023 60
P.Qty.	1	12	12
Chemical basis	Moisture-hardening 1-component polyurethane	Moisture-hardening 1-component polyurethane	Moisture-hardening 1-component polyurethane
Drive-away time (with airbag)	1 h	1 h	1 h
Drive-away time (without airbag)	30 min	30 min	30 min
Container	Cartridge	Cartridge	Bag
Content	310 ml	310 ml	400 ml

### Note

Fully clean the inside of the new window with Würth Active Cleaner and then wipe it dry! In addition, thinly apply Würth Contact Clean using a clean, lint-free cloth in a single pass and wipe it with a dry, clean cloth afterwards. If the vehicle flange was damaged upon cutting back the remaining adhesive bead (bare metal), Würth Varioprimer must be applied twice to prevent corrosion, taking into account the specified flash-off time. The products must be checked to ensure that they have not expired before they are used. Apply adhesive while guiding the gun vertically, starting from the center at the bottom of the window. Do not place the vehicle on a lifting platform. Observe the information provided by the vehicle manufacturer in regard to bead geometry. The application and drive-away times must be observed.

Supplement to Art. No.:	Designation	Art. No.
0890 023 50	Varioprimer safe + easy	<b>0890 024 010</b> <b>0890 024 021</b>
	Glass Cleaner Active Cleaner	<b>0890 024 1</b>
	Adhesion Agent Contact Clean	<b>0890 024 5</b> <b>0890 024 500</b>
	Adhesion Agent Contact Clean Pad	<b>0890 024 515</b>
0890 023 60	Varioprimer safe + easy	<b>0890 024 010</b> <b>0890 024 021</b>
	Glass Cleaner Active Cleaner	<b>0890 024 1</b>
	Adhesion Agent Contact Clean	<b>0890 024 5</b> <b>0890 024 500</b>
	Adhesion Agent Contact Clean Pad	<b>0890 024 515</b>

### Instructions

A clean environment is to be selected for application. Use of the product with the accompanying Würth system components is essential for properly performed and problem-free work. The work instructions accompanying the product must be followed during application.

This information is only a recommendation based on our experience. Preliminary testing required! For further information, see the technical information leaflet.