



mm	D mm	L mm	Art.-Nr.	Pack Qty.
8	25	65	<b>0690 410 8</b>	1

## Stud Extracting Tool

- For removing and inserting studs with or without thread within seconds.
- No damage to stud by welding on auxiliary means, (nuts or similar) or use of pliers.
- Countering of nuts not necessary.
- Grips studs with a minimum length of 10 mm.
- A tool with no wearing parts.



## Stud Extracting Tool Assortment

**Art. No. 0690 421 1**

Contents: 1 each for Ø 6, 8, 10 and 12 mm. Supplied in metal box with a plastic insert.



Size	For Screws		Length mm	Req. drill Ø mm	Art. No.	Pack Qty.
	mm	inch				
1	M 3 – 6	1/8 – 1/4	50	1.8	<b>0695 347 940</b>	1
2	M 6 – 8	1/4 – 5/16	57	2.6	<b>0695 348 127</b>	
3	M 8 – 11	5/16 – 7/16	64	3.7	<b>0695 348 314</b>	
4	M 11 – 14	7/16 – 9/16	71	5.5	<b>0695 348 501</b>	
5	M 14 – 18	9/16 – 3/4	78	7.0	<b>0695 348 688</b>	
6	M 18 – 24	3/4 – 1	95	11.0	–	
7	M 24 – 33	1 – 1 3/8	105	14.0	–	
8	M 33 – 50	1 3/8 – 2	111	21.0	–	

## Stud Extractor

- For removing broken-off studs or threaded bolts. A hole is bored into the parts to be removed according to the Table and the extractor is screwed in to the left. By means of further tightening the broken-off part is extracted without damaging the thread.
- Chrome Vanadium, forged.

## Stud Extractor Set

- In plastic boxes.
- Chrome Vanadium, forged.

Cont.: 1 screw extractor each	Art. No.	Pack Qty.
Size 1 – 5	<b>0695 684 353</b>	1
Size 1 – 6	<b>0695 684 540</b>	
Size 1 – 8	<b>0695 684 727</b>	